T09227 "5082E00T



FIG. 1

FIG. 2


Application Layer
202
Application Developer Code
210
Platform API
204
LbsDeviceLocatorManager
212
Internal Implementation
206
Ericsson MPS Adapter
Ericsson MPS Client Code
Carrier X LDT Adapter
Carrier X LDT Client Code
124
216
Remote LDT Providers
208
Ericsson MPS Server Code
Carrier X LDT Server Code
218

FIG. 3



EP 0 865 225 B1

FIG. 4


INVOKE SIMPLIFIED PROCEDURES OF API
400
OBTAIN LOCATION OF MOBILE DEVICE
402
INTERACT WITH CARRIER ADAPTER
404
OBTAIN DESCRIPTION OF SRS
406
REFINE LOCATION
408